

Chasico





























Manual de instrucciones

Instructions Manual
Notice d'Utilisation
Manual de instruções

Barbacoa portátil

Portable steel barbecue
Barbecue portable
Churrasqueira de aço portátil

vassary®
cooking with love 

1X1 	2X1 	3X1 	4X1 
5X1 	6X3 	7X1 	8X2 
9X1 	10X1 	11X1 	12X1 
13X1 	14X1 	15X1 	16X2 
17X2 	18X3 	19X1 	20X2 
AXM4X10mmX2   	BXM6X16mmX6 	CXM6X35X3 	DX ϕ 16mmX3 
EXM6X2  	FX ϕ 20mmX6 